

257.5

SEMI RECESS BASIN TEMPLATE

1. CAREFULLY CUT ALONG THE DOTTED LINES TO CREATE THE BASIN TEMPLATE.
2. FOLD AS INDICATED BELOW AND POSITION ALONG THE TOP EDGE OF THE TOP PANEL.
3. POSITION THE TEMPLATE CENTRAL TO THE TOP PANEL.
4. CAREFULLY MARK WITH A PENCIL THE CUT-OUT REQUIRED. FLIP THE TEMPLATE AND REPEAT.

CENTRE LINE OF TOP PANEL

392

FOLD AND POSITION ALONG THE TOP EDGE OF TOP PANEL

